

embertec[®]


SmartSwitch[™] AV

Quick Installation Guide Embertec SmartSwitch[™]

1. Switch off the power at the wall socket and unplug your appliances from the wall socket.
2. Identify equipment that requires constant power for timers, program guides and recording features, and plug them into the socket marked 'Always On', or another wall socket. A powerboard may be plugged into the 'Always On' socket.
3. Plug your AV equipment that can be automatically switched off into a powerboard (powerboard not supplied).
4. Connect the powerboard to the 'Power Saver' socket.
5. Connect the supplied SmartSensor cable to the underside of the Embertec SmartSwitch[™] AV and make sure that it fits securely in the socket.
6. Place the SmartSensor in a convenient location that is in line of sight. Close to your television is the best position, and within normal operation of your existing remote control(s).
7. Plug the Embertec SmartSwitch[™] AV into a 230V or 240V power point, and turn the power point on at the wall. (This is the standard power in all Australian homes).
8. The LED monitoring light on the Embertec SmartSwitch[™] AV will now light up for 3 seconds to indicate detection of connected equipment. This also indicates the Embertec SmartSwitch[™] AV is monitoring your power consumption and providing power to the 'Power Saver' socket.
9. Now turn on your equipment as normal.

embertec[®]

SmartSwitch[™] AV



Maximum Savings, Zero Effort!

Embertec Pty. Ltd. 182 Fullarton Road, Dulwich, SA 5065, Australia

Phone : 1300 033 367 Email: customerservice@embertec.com

embertec[®]
ENERGY EFFICIENCY TECHNOLOGIES